

LP	ROZDZIELNICA	ILOŚĆ BOKSÓW	Pi [kW]	Kz	Ps [kW]	Pp [kW]	cos fi	Qz [kVAr]	Sz [kVA]	ILOŚĆ FAZ	Iobc [A]	Izab w RG [A]	Izab w ZŁĄCZU [A]
Targowisko													
1	SZAFKA ZŁĄCZOWO-POMIAR. 1												
1.1	W.L.Z. box otwarty	39	4,0	1	4,0	4,0	0,93	1,6	4,3	1	18,7	20	
	SZAFKA ZŁĄCZOWO-POMIAR. 1	39	159,9	0,3	39,0	156,0	0,93	15,4	42,0	3	60,6		100
2	SZAFKA ZŁĄCZOWO-POMIAR. 2												
2.1	W.L.Z. box zamknięty	15	12,0	1	12,0	12,0	0,93	4,7	12,9	3	18,6	20	
2.2	W.L.Z. administracja	1	20,0	1	20,0	20,0	0,93	7,9	21,5	3	31,1	32	
	SZAFKA ZŁĄCZOWO-POMIAR. 2	15	142,2	0,4	60,3	200,0	0,93	23,8	64,9	3	93,7		125
	ZŁĄCZE KABLOWE ZK1		363,5	0,4	99,3	356,0	0,93	39,3	106,8	3	154,3		200